

Installing Protective Wall Art (PWA) using Spray-Lock

READ THESE INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.
USE THESE INSTRUCTIONS IN CONJUNCTION WITH CS SHOP DRAWINGS.

STEP 1 - PREPARATION

1. Ensure the substrate surface is clean, dust-free, no oils, etc.
NOTE: Prime joint compound with latex-based primer.
2. Take the necessary precautions to protect surrounding surfaces from adhesive overspray.

GENERAL APPLICATION

1. Dry-fit each sheet to ensure proper fit prior to applying adhesive to the substrate.
2. Shake can of adhesive vigorously.
3. Hold the spray can 18-20 inches from substrate (adjust distance as needed for a uniform spray pattern). Apply Spray-Lock uniformly to the substrate (coverage should equal 2 sheets per can). This should look similar to a popcorn acoustic ceiling texture.
4. If sections appear thin, lightly apply more adhesive. Refer to the spray pattern photo on the Spray-Lock installation guide provided in each case of adhesive.
5. Wait for the adhesive to “tac” up. This may vary based on temperature and humidity. Proper tac is achieved in 10-20 minutes when adhesive becomes transfer free. Test: lightly touch adhesive – there should be no adhesive transfer to your fingers. Follow instructions that are on the adhesive container.
6. Place the Protective Wall Covering to the substrate
7. Using a Floor Tile Roller (as seen in photo below), roll from the center of sheet outward using a firm amount of pressure when rolling.
8. Clean up any overspray immediately using a damp cloth, while the adhesive is still wet.

NOTE: For additional information regarding proper installation with the Spray-Lock adhesive, please reference the installation guide included in each case of Spray-Lock adhesive.



Floor Tile Roller or similar roller with rubber wheels